




51 7309
Gebrauchsanweisung
(D)

51 1936
Tips und Rezepte

- 1) 05 3176
- 2) 02 1947
- 3) 02 5992
- 4) 01 8981
- 5) 05 1477
- 6) 08 3566

Zubehör:

Alu-Backblech
Z1300X1

Email-Backblech
Z1310X1

Bratpfanne
Z1200X1

Rost
Z1400X1

