




Gebrauchsanweisung

51 4852

(D,GB,F,I,NL)

Tips und Rezepte

51 3804

(D)

Montageanleitung

51 0703

(D,GB,F,I,NL)

Zubehör:

HZ 8042

Bratpfanne

HZ 8044

Spritzschutzpfanne

HZ 8048

Alu-Backblech

HZ 8057

Universalpfanne

HZ 8087


Backblech emailliert

HZ 9150

Glasbräter

1) 27 3322
D1
27 3321
D2

2) 03 2955
D1
03 2954
D2



- 1) 04 3326
500 Ohm
- 2) 04 3326
500 Ohm
- 3) 08 8413
- 4) 08 8410
- 5) 02 6589
- 6) 11 3908
- 7) 11 9303

