


**BOSCH**

WFK5000-WFK5000/01-D1
 WFK5000-WFK5000FG/01-FG1
 WFK5000-WFK5000/02-D2
 WFK5000-WFK5000FG/02-FG2

WASCHGERÄTE
 Waschvollautomaten



Aufstellanweisungen:

51 3556
 (D,I,S,N,SF)
 51 3557
 (S,DK)
 51 3558
 (NL,F,E,GB)

Ident - Nummern - Konstante
 3740


1) 08 6336
 (D)
 08 6337
 (NL)
 08 6338
 (N)
 08 6339
 (SF)
 08 6340
 (S)
 08 6341
 (E)
 08 6342
 (F)
 08 6343
 (DK)
 08 6344
 (I)
 08 6686
 (TR,YU,E,GB)
 08 6690
 (GB)

Gebrauchsanweisungen:

51 3566
 (D,I,S,N,SF)
 51 3567
 (S,DK)
 51 3568
 (NL,F,E,GB)

Programmtabellen:

51 3552
 (D)
 51 3553
 (I,S,N,SF)
 51 3554
 (S,DK)
 51 3555
 (NL,F,E,GB)




**BOSCH**

WFK5000-WFK5000/01-D1
 WFK5000-WFK5000FG/01-FG1
 WFK5000-WFK5000/02-D2
 WFK5000-WFK5000FG/02-FG2

WASCHGERÄTE
 Waschvollautomaten

Ident - Nummern - Konstante
 3740


1) 27 0442
 15 5272
 Triac-Motorleistung



**BOSCH**

WFK5000-WFK5000/01-D1
WFK5000-WFK5000FG/01-FG1
WFK5000-WFK5000/02-D2
WFK5000-WFK5000FG/02-FG2

WASCHGERÄTE
Waschvollautomaten



Ident - Nummern - Konstante
3740