




Aufstellanweisungen


51 1221
(D,F,I,NL,GB,E)
51 1337
(D,F,I,S,DK,N)
51 1584
GB1


Gebrauchsanweisungen

51 1222
(D,F,I,NL,GB,E)
51 1489
(D,F,I,S,DK,N)

Programmtabellen

51 1223
(D,F,I,NL,GB,E)
51 1490
(D,F,I,S,DK,N)
51 1355
GB1





- 1) 07 3594
220 V - 1500 W
07 3592
220 V - 950 W
07 3981
240 V
- 2) 14 0376
220 V
14 0452
240 V

