




51 4893
Gebrauchsanweisung
(D,GB,F,NL,I,E)

51 2001
Tips und Rezepte
(D)

51 2726
Montageanweisung
(D,GB,F,NL,I,E)

1) 02 4343
A1,A4
01 8981
A2,A3

Zubehör:

Grillpfanne
Z1220X0

Alu-Backblech
Z1320X0


**Back- und
Bratrost**
Z1420X0

Teleskopschiene
Z1721X0

Bratenblech
Z1510X0

Drehspiess-Set
Z1162X0

Brotbackstein
Z1910X0



- 1) 05 3112
- 2) 05 4679
- 3) 05 4676
- 4) 02 7966
- 5) Düsensätze für
Stadtgas
02 1936
Erdgas
02 1937
Flüssiggas
05 2418
- 6) 08 4725
- 7) 08 4731
- 8) 08 4732

Zubehör

Anschlußgarnitur (FL)
Z2300X0
Düsenatz Flüssiggas
Z2232X0
Düsenatz Erdgas
Z2222X0
Düsenatz Stadtgas
Z2212X0
Gasschlauch
Z2500X1

