


**BOSCH**

HMG2004/00-D1, braun
HMG200463/00-B1, braun
HMG200467/00-NL1, braun

HMG200469/00-F1
HMG200489/00-GB1

HERDE
Mikrowellenherde

Ident-Nummern-Konstante
3740



51 3312
Gebrauchsanweisung
(D,GB,F,I,NL)
Kochbuch + MW
51 2801
(D)
51 2803
(F)
51 3232
(NL)
51 2802
GB
51 3684
Kurzanleitung
(D)


**BOSCH**

HMG2004/00-D1, braun
 HMG200463/00-B1, braun
 HMG200467/00-NL1, braun

HMG200469/00-F1
 HMG200489/00-GB1

HERDE
 Mikrowellenherde

Ident-Nummern-Konstante
 3740



- 1) 11 6665
- 2) 11 6684
- 3) 11 4538
Backblech
02 8732
Anschlagteil
- 4) Seitenblech
kompl.
27 0006
links
27 2084
rechts
- 5) 03 1615
rechts
03 1616
links


**BOSCH**

HMG2004/00-D1, braun
HMG200463/00-B1, braun
HMG200467/00-NL1, braun

HMG200469/00-F1
HMG200489/00-GB1

HERDE
Mikrowellenherde

Ident-Nummern-Konstante
3740



**BOSCH**

HMG2004/00-D1, braun
HMG200463/00-B1, braun
HMG200467/00-NL1, braun

HMG200469/00-F1
HMG200489/00-GB1

HERDE
Mikrowellenherde

Ident-Nummern-Konstante
3740

