


**BOSCH**


S712-SMS71224/00-I1

GESCHIRRSPÜLGERÄTE
StandgeräteIdent-Nummern-Konstante
3740


51 3033
EU1,I1
Gebrauchsanweisung
(D,GB,F,I,NL)
51 2277
Aufstellanleitung

- 1) 04 2085 Set
- 2) 04 2105 Set
- 3) 01 9177 Set
- 4) 02 5122
- 5) 02 5123
- 6) 02 2459
- 7) 02 5657 rot
- 8) 02 5658 grün
- 9) 02 5824
- 10) 11 7673 EU1,I1
11 8276 I2
- 11) 02 1237


Ident.-Nummern-Konstante
3740



- 1) 08 0781 Set
- 2) 02 5067 Set
- 3) 01 9204 Set
- 4) 20 1073 EU1
- 5) 05 1838




Ident-Nummern-Konstante
3740



- 1) 01 3861
- 2) 02 7386
- 3) 20 3079
EU1,I1
20 3611
I2

Ident-Nummern-Konstante
3740 .. .



- 1) 01 9202
- 2) 11 0668
Set
- 3) 05 1287
Set
- 4) 20 1970
EU1
20 3631
11,12