




Gebrauchsanweisung

51 3926
(D, F, GB, I, NL)

Kurzanweisung

51 3927

(D)

Kochbuch

51 3930

(D)

51 4061

(NL)

51 4062

(F)

Zubehör:

Einbaurahmen

HZ 67020

kratzfeste Abdeckung

HZ 67720

Alu-Backblech

HZ 8055


Glaspfanne

HZ 8056

Glasbräter

HZ 9150

- 1) 03 0681
grün
- 2) 03 0680
weiss
- 3) 03 0679



- 1) 03 0671
2) 03 0813
Arretierstift

