





Ident – Nummern – Konstante
3740

Gebrauchsanweisung

58 2918
V01, V02, V03
69 9832
V04
(NE)
58 2919
V01, V02, V03
69 9831
V04
(NE)

- 1) 17 3891
V01
42 4423
V02, V03, V04
- 2) 18 8619
- 3) 26 7356
- 4) 26 7357
- 5) 26 7359
- 6) 36 2412
- 7) 18 3762



Ident - Nummern - Konstante
3740

1) 16 9339

Duesensatz Für:
EG H/E G20 20mbar
17 4049

FG G30/31 30mbar
17 4048

EG H/E G20 20mbar
(inkl.Bypass-Dusen)
41 7597

FG G30/31 30mbar
(inkl.Bypass-Dusen)
41 7837