



Gebrauchsanweisung
52 7364

1) 18 1397

2) 18 1397





1) 17 4967

Erdgas

2) 18 1323

Ø 0.67

3) 18 1275

Ø 1.30

Stadtgas

2) 17 6855

Ø 1.15

3) 18 1398

Ø 2.50

Flussgas

2) 18 1324

Ø 0.42

3) 18 1285

Ø 0.87