




Gebrauchsanweisung
52 3179
(de,en,fr,nl,it,es,el)

1) 17 1322
2) 17 1323

Düsensätze:






Erdgas-E 20 mbar
17 1280

Erdgas-LL 20 mbar
17 1281


Flüssiggas (LPG)
30/37 mbar
17 1279

Flüssiggas 50 mbar
17 1252

Einbausatz
17 1337



- 1) 17 1326
Set
- 2) 16 7363



- 1) 35 4139
- 2) 16 6325
- 3) 17 1337