

**BOSCH**

WFK5010-WFK5010/01-D1

WFK5010-WFK5010CH/01-CH1

WFK5010-WFK5010FG/01-FG1

WFK5010-WFK5010SI/01-SI1

WFK5010-WFK5010DS/01-DS1

WASCHGERÄTE
WaschvollautomatenIdent - Nummern - Konstante
3740

1) 08 6336
(D)
08 6337
(NL)
08 6338
(N)
08 6339
(SF)
08 6340
(S)
08 6341
(E)
08 6342
(F)
08 6343
(DK)
08 6344
(I)
08 6686
(TR,YU,E,GB)
08 6690
(GB)

Gebrauchsanweisungen:


51 3566
(D,I,S,N,SF)
51 3567
(S,DK)
51 3568
(NL,F,E,GB)


Programmtabellen:

51 3552
(D)
51 3553
(I,S,N,SF)
51 3554
(S,DK)
51 3555
(NL,F,E,GB)

Aufstellanweisungen:

51 3556
(D,I,S,N,SF)
51 3557
(S,DK)
51 3558
(NL,F,E,GB)





**BOSCH**

WFK5010-WFK5010/01-D1
WFK5010-WFK5010CH/01-CH1
WFK5010-WFK5010FG/01-FG1
WFK5010-WFK5010SI/01-SI1

WFK5010-WFK5010DS/01-DS1

WASCHGERÄTE
Waschvollautomaten

Ident - Nummern - Konstante
3740

1) 11 9900
15 5272
Triac-Motorleistung

