


**BOSCH**



BOSCH T 480 — 0 728 144 115—D1
 — 0 728 144 116—GB1
 — 0 728 144 117—CH1,DK1,S1

WASCHGERÄTE
 Trockner

Ident-Nummern-Konstante
 3740



Aufstellanweisungen
 51 2796
 (D,GB,F,I,NL,E)
 51 2797
 (D,F,I,DK,S)
Gebrauchsanweisungen
 51 2794
 (D,GB,F,I,NL)
 51 2795
 (D,F,I,DK,S)



Ident-Nummern-Konstante
3740

- 1) 02 0159
- 2) 01 5938
- 3) 01 5942
- 4) 05 1104
- 5) 01 5940
- 6) 02 8310




BOSCH


BOSCH T 480 – 0 728 144 115–D1
– 0 728 144 116–GB1
– 0 728 144 117–CH1,DK1,S1

WASCHGERÄTE
Trockner

Ident-Nummern-Konstante
3740




Ident-Nummern-Konstante
3740



- 1) 02 1439
- 2) 14 0368
D1,CH1,DK1,S1
14 0369
GB1
- 3) 08 7263
D1
08 7264
GB1
08 1624
CH1
- 4) 02 7014
D1,GB1
02 5756
CH1,DK1,S1

Ident-Nummern-Konstante
3740



- 1) 05 3948
3uF
Kühlgebläse
- 2) 07 4627
2uF
Umluftgebläse
- 3) 08 3375
bis FD 6609
08 5679
ab FD 6610