




	5111
122343	5133
138128	5154
142308	5140




	LINE	PIN
102613	5111	
PAGE 2	5133	4PIN
138129	5154	
PAGE 2	5133	6PIN
PAGE 2	5133	4PIN
142307	5140	




	LINE	PIN
102781	5111	
PAGE 2	5133	4PIN
134237	5154	
PAGE 2	5133	6PIN
PAGE 2	5133	4PIN
142309	5140	



102783	5111
118486	5133
133710	5154
142304	5140



102616	5111
113535	5133
134230	5154
142306	5140



ACCESSORY



119527

123919 TSBW01




ATTENZIONE VERIFICARE N° PIN

ATTENTION CHECK PIN NUMBER

ATENCIÓN COMPROBAR NÚMERO PIN

ATTENTION VÉRIFIER LE NUMÉRO DE PIN

ACHTUNG PIN-NUMMER ÜBERPRÜFEN



	LINE	PIN	
140190	5133	4PIN	0190-200-03621
140191	5133	6PIN	0190-200-05921
140192	5133	4PIN	0190-200-06021-1

	LINE	PIN	
140559	5133	4PIN	0190-200-03521
140560	5133	6PIN	0190-200-06121
140561	5133	4PIN	0190-200-03521