





Bedienungsanleitung
51 6341
V01,V02
51 6961
V03–V08
Zubehör:

Luftschlauch
48/0231



- 1) 07 2714
V01, V02, V04, V06
15 0517
V03, V05, V07, V08
- 2) 06 5614
V01, V02, V04, V06
16 2329
V03, V05, V07, V08
- 3) 29 7085
Umrüstsatz
4-Pkt. auf 3-Pkt.-
Befestigung
V01, V02