




Gebrauchsanweisung
51 6756
(D,GB,F,NL,I,E,GR)

51 2001
Tips und Rezepte

Zubehör

Back- und
Bratrost normal
Z1400X1


Back- und
Bratrost eng
Z1410X1


Grillpfanne
Z1200X1


Email-Backblech
Z1310X1




Alu-Backblech
Z1300X1

Bratenblech
Z1510X0









1) 08 4701
 kompl.

