




NEFF
Elektroherd

Herde und K cheneinrichtungen

1824/ 1824 U/ 1824 E/ 1824 EF/
1824 EU/ 1824 EUFG/ 1824 EUF



1) 380 V

2) nur f. 1824 EF, 1824 EUF, 1824 EUFG



NEFF
Elektroherd

Herde und Kücheneinrichtungen

1824/ 1824 U/ 1824 E/ 1824 EF
1824 EU/ 1824 EUFG/ 1824 EUF

05 2445/01

12 5522/08
07 4358/15 ¹⁾

02 3892/01/5

08 1756/26

02 3863/01/2

05 2978/05

02 3777/08 ³⁾

01 7747/02/10

02 4834/01

02 2859/01/5

1) 380 V


3) 05 2470/08 Signallampe kpl. (gelb)



Elektroherd

Herde und Kücheneinrichtungen

1824/ 1824 U/ 1824 E/ 1824 EU
1824 EUFG/ 1824 EF/ 1824 EUF



1) f. 1824, 1824 U, 1824 E

2) f. 1824 EU, 1824 EF, 1824 EUFG




NEFF Herde und Kücheneinrichtungen

Elektroherd

1824/1824 U/1824 E

1824 EU/ 1824 EUFG

1824 EF/ 1824 EUF



1) 220 V

2) 380 V