



**BOSCH**

S212 - SMS 2120G - 0 730 103 574-CH1

GESCHIRRSPÜLGERÄTE
StandgeräteIdent.-Nummern-Konstante
3740

51 1552
CH1
Gebrauchsanweisung
(D,GB,F,I,NL,DK,P,E)
51 2277
Aufstellanleitung

- 1) 04 2085
Set
- 2) 04 2105
Set
- 3) 01 9177
Set



Ident Nummern Konstante
3740

1) 08 0781
Set


2) 02 5067
Set


3) 01 9204
Set

4) 05 1838

6) 20 2292
1700 W

7) 08 3501
1300 W





Ident-Nummern-Konstante
3740

- 1) 08 2970
- 2) 08 2971
- 3) 01 3861
Set
- 4) 02 7386

Ident-Nummern-Konstante
3740

- 1) 01 9202
- 2) 11 0668
- Set
- 3) 05 1287
- Set

