






Kullanma kilavuzu
58 5317

1) 16 5552


35 4598



26 2266



3) 1)
3) 1)
3) 1)
3) 1)



26 6534




26 7022




26 6534




26 7022



26 7022




35 5958



26 6528

26 6529



26 7023



35 5309

35 4931

21 6864


V01,V02

21 8856

V03

21 6799


18 1768



26 6533

16 6484

17 1319



23 6374


V01,V02

23 8423

V03

23 6353

- 1) 36 0391
- 2) 17 1321
- 3) 35 4780
- 4) 35 8292
- 5) 35 8293



Pos.	Danfoss		
	NL10F		
1	14 2196		
2	16 5570		
3	16 3427		
4	35 4583		
5	17 1318		
6	26 5327		
7	17 1519		
8	18 1014		
9			
10			
11			
12			

TECHNISCHE DATEN/TECHNICAL DATA/TEKNIK BILGILER

Verdichter/Compressor/Kompresör	Danfoss		
Typ/Type/Tip	NL10F		
Förderleistung/Delivery/Verim/h			
Anlaufstrom/Starting current/Giris akimi	A	13.6	
Widerstand/Resistance/Rezistans Ha/	Ohm	8.2	
Hi/aux.		14.7	
Temp.Reyler/Thermostat/Termostat	K59/P1777		
Typ/Type/Tip			
Reglerstellung/Position/Termostat pozisyonu			
Schaltwerte/Actua kapama degerleri	..ein/acma °C	+3.5 +3.5	
Valeurs de commutation/Termostat degeri	..aus"/kapama	-31 -20	
(..abtaven' od)	..alarm'		
Füllmenge/Fill. quantity/ Dolum miktarı	R134a	g	
		g	
Anschlusswert/Comm. load/Giris gucu	W	*	
Heizung/Heater/Rezistans			
Widerstand/Resistance/Direnc	Ohm		
Leistung/Power/Guc	W		
Ventilador/Blower/Vantilatör			
Widerstand/Resistance/Rezistans	Ohm		
Magnetventil/Magnetic valve/Manyetik valf			
Widerstand/Resistance/Rezistans	Ohm		
Spannung/Voltage/Gerilim	V		
Temp.Reyler/Thermostat/Termostat			

* Siehe Typenschild/Mamul etiketine bakınız