





Gebrauchsanweisung


51 5513
D1,D2,A1,A2
(D)
51 6862
D3
(D,GB,NL,F,I,E,P,GR,
DK,S,N,SF)
51 7119
D4

- 1) 08 4641
- 2) 08 4642
- 3) —
- 4) 02 1519
D1
03 1177
D2,A1,A2,D3,D4
- 5) 05 5235
D1,D2,A1,D3,A2
15 0932
D4
- 6) —
- 7) 08 7444
D1,A2
08 8319
D2,A1
15 0099
D3
09 4959
D4
- 8) 08 6717
- 9) 02 8213
- 10) 28 0884
D1,D2,D3,A1,A2
28 6528
D4




Zubehör:

Electromatic–Bürste
VE 24022
schwarz
Turbo–Universal–
Bürste
VZ 470900
schwarz
Polieraufsatz–Formula
VZ 27027



1) 05 9656



02 7109
schwarz

08 0857
schwarz
09 4962
schwarz
D4

02 9169

45 0759
schwarz
46 0435
D4
schwarz
kompl.

28 7684

46 0097
schwarz
46 0380
schwarz
D3,A2,D4

45 0140
Metall

45 0679
schwarz
46 0381
schwarz
D3,A2,D4

28 6468
D4

46 0012
schwarz

45 0773
schwarz
46 0382
schwarz
D3,A2,D4