





Libro de instrucciones  
52 0368  
(E)



| Pos. | Zanussi  |  |
|------|----------|--|
|      | GL 45 AA |  |
| 1    | 14 1354  |  |
| 2    | 15 4345  |  |
| 3    |          |  |
| 4    |          |  |
| 5    |          |  |
| 6    |          |  |
| 7    |          |  |
| 8    |          |  |
| 9    | 03 7186  |  |
| 10   |          |  |
| 11   |          |  |
| 12   |          |  |
| 13   |          |  |

## TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS

|                                                            |         |  |
|------------------------------------------------------------|---------|--|
| Verdichter/Compressor/Compresseur/Compresor                | ZANUSSI |  |
| Typ/Type/Tipo                                              | GL45AA  |  |
| Förderleistung/Delivery/Debit/Aspiración l/h               |         |  |
| Anlaufstrom/Starting current/Cour.démarrage/Int.arranque A | 8,3     |  |
| Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm       |         |  |
| Hi/aux.                                                    |         |  |

|                                   |           |  |
|-----------------------------------|-----------|--|
| Temp.Reyler/Thermostat/Termostato | DANFOSS   |  |
| Typ/Type/Tipo                     | 077B0008  |  |
| Reglerstellung/Position/Conexión  | MIN. MAX. |  |
| Schaltwerte/Switching values/     | -18 -25   |  |
| Valeurs de commutation/Desconex.  | -24 -33   |  |
| (..abtaven' od)                   | ..alarm   |  |

|                                             |   |  |
|---------------------------------------------|---|--|
| Füllmenge/Fill. quantity/Charge/Carga R134a | g |  |
|---------------------------------------------|---|--|

|                                                 |   |    |
|-------------------------------------------------|---|----|
| Anschlußwert/Comm. load/puiss. Connect./Potenc. | W | 78 |
|-------------------------------------------------|---|----|

|                                             |     |  |
|---------------------------------------------|-----|--|
| Heizung/Heater/Chauflage/Resistenc.descong. |     |  |
| Widerstand/Resistance/Resistencia           | Ohm |  |
| Leistung/Power/Puissance/Potencia           | W   |  |

|                                          |     |  |
|------------------------------------------|-----|--|
| Ventilador/Blower/Ventilateur/Ventilador |     |  |
| Widerstand/Resistance/Resistencia        | Ohm |  |

|                                                         |     |  |
|---------------------------------------------------------|-----|--|
| Magnetventil/Magnetic valve/Electrovanne/Electrovalvula |     |  |
| Widerstand/Resistance/Resistencia                       | Ohm |  |
| Spannung/Volare/Tension/Tensión                         | V   |  |

|                                                                         |  |  |
|-------------------------------------------------------------------------|--|--|
| Temp.Reyler/Thermostat/Termostato ambiente para ventilador refrigerador |  |  |
|-------------------------------------------------------------------------|--|--|