




Gebrauchsanweisung
58 6345

1) 41 7587

2) 43 1499

3) 26 8009

4) 41 7579

5) 26 7357

6) 26 7359

7) 26 7356

8) 17 3897

9) 17 3898

10) 17 3896

11) 26 8644

12) 26 8010

13) 18 4302

14) 23 9221

V01, V02

24 1385

V03, V04

15) 16 8053

16) 41 6914

V01, V02

17) 43 1502

18) 42 3351

V03, V04

19) 42 3352

V03, V04

20) 42 3353

V03, V04

21) 42 3354

V03, V04

49 0485

V01,V02



49 2375

V03,V04


V05,V06

49 4989

V07,V08



41 6860



1) 42 0420

2) 18 8150

3) 18 8153


4) 18 8148

V01,V02,V03,V04


42 5331

V05,V06,V07,V08


5) 18 4297



- 1) 35 3489
- 2) 36 5988
- 3) 41 7587



- 1) 48 8843
V01,V02,V03
49 3152
V04,V05,V06,V07
V08



1) 16 9339

2) 17 3894

3) 17 3895

4) 26 7362

5) 26 7363

6) 26 7360

7) 35 8149

8) 35 8150

9) 48 0000

10) 17 5431

V01,V02,V03,V04

42 4846

V05,V06,V07,V08

11) 17 5430

V01,V02,V03,V04

42 4845

V05,V06,V07,V08

Duesensatz Für:
EG H/E G20 20mbar
17 3900

FG G30/31 30mbar
17 3899

EG H/E G20 20mbar
(inkl.Bypassdusen)
41 7595

FG G30/31 30mbar
(inkl.Bypassdusen)
41 7838