




Mat. - Nr. - Konstante
3740

Gebrauchsanweisung
58 5874

1) 41 7587
2) 17 3896
3) 16 8053
4) 41 7579
5) 26 7357
6) 26 7359
7) 26 7356
8) 17 3897
9) 17 3898
10) 43 1499
11) 18 4302
12) 41 6914

V01, V02

13) 23 9187
V01, V02
24 1285
V03

14) 43 1502
15) 42 3351
V03


16) 42 3352
V03


17) 42 3353
V03

18) 42 3354
V03

Mat. – Nr. – Konstante
3740


- 1) 18 8160
- 2) 41 7829
- 3) 18 8170






Mat. – Nr. – Konstante
3740

Mat. – Nr. – Konstante
3740





Mat. - Nr. - Konstante
3740

- 1) 16 9339
- 2) 26 7362
- 3) 26 7363
- 4) 26 7360
- 5) 35 7811
- 6) 35 7810
- 7) 35 7809
- 8) 35 7808
- 9) 17 3894
- 10) 17 3895

Duesensatz Für:
EG H/E G20 20mbar
17 5536

FG G30/31 30mbar
17 5537

EG H/E G20 20mbar
(inkl.Bypassduesen)
41 7596

FG G30/31 30mbar
(inkl.Bypassduesen)
41 7840