





Gebrauchsanweisung
52 7219
(de,fr,it)


Montageanweisung:
52 4061
(de,en,fr,it,nl,dk,se,no,
fi,es,pt,gr,cz,pl,tr,ru)


Zubehör:
HZ8050
Backblech Alu
HZ21100
Backblech emailliert
HZ21300
Universalpfanne
HZ21400
Kombirost
HZ21700
Profi-Auszug
HZ24701
Deckel f. Profipfanne
HZ22500
Grillblech
HZ9150
Glasbräter
HZ26000
Metallbraeter
HZ25300
Aktiv-Kat.
HZ25001
Adapterkabel
HZ21610
Katalyse-Set

1) 01 4254

1) 26 0928
Set







1) 21 5569
Set

