




51 7316
Gebrauchsanweisung
(D,F,NL,I)

51 4969
Tips und Rezepte
(D)

- 1) 05 3176
- 2) 02 1947
- 3) 02 5992
- 4) 01 8981
- 5) 05 1477
- 6) 08 3566


Zubehör:

Alu-Backblech
Z1300X1


Email-Backblech
Z1310X1


Bratpfanne
Z1200X1


Rost
Z1400X1



1) 02 2695







1) 09 5120
Set