




Mat. – Nr. – Konstante	
3740	

Gebrauchsanweisung
(de,en,fr,nl,it,es)
52 3341

1) 16 7354

Düsensätze:

Flüssiggas 50mbar
17 1620

Flüssiggas 30mbar
16 7552

Erdgas E20mbar
16 7553

Erdgas L, 25mbar
(NL)
16 9553

